



MetalArt Care & Handling

Care:

MetalArt can be cleaned using a soft cloth or towel. Avoid paper towels and scratchy textures. If needed, use water or window cleaner (windex) to remove fingerprints and dusts.

Handling

For MetalArt with Float Mounts, please make sure to remove all tape securing the art to the box, so that the art is not bent when you remove it from the box.

For MetalArt with Flush or Inset Frames, please be careful not to twist the frame when removing the art from the box or crate. After cutting the plastic strapping bands, lift one side straight up and rest the art gently along the other edge, carefully removing any foam packing strips.

Careful not to drop or bump the edges or corners.

Hanging

Framed MetalArt can be hung using the wire hanger provided or directly from the inside edge of the frame with a wall hook.

Make sure that your wall hooks are appropriate strength to hold the weight so that art does not fall. You may want to install wall anchors or other secure hanging devices.